

CLIPSTRIP

2FW Floor Warming Cable Strapping



DESCRIPTION

Galvanized stainless steel strapping is designed for anchor 2FW cable to the subfloor in an easy consistent pattern.

The punched tabs are spaces 1" (2.5cm) apart.

Each ClipStrip roll is W/L .5"/25' (1cm/8m).

INSTALLING

Lay two parallel rows of ClipStrip strapping on top of the subfloor.

Using the supplied screws, secure the strapping on top of the subfloor. Glue to clean concrete with hotmelt.

The ClipStrip strapping tabs are spaced 1" (2.5cm) apart. Using the tabs, secure the 2FW cable to the strapping at the correct specified cable spacing. Refer to Detail 1.

Please call Delta-Therm at 1-800-526-7887 if you have any questions.



Detail 1. Attaching 2FW cable to ClipStrip strapping.

TECHNICAL SUPPORT

A full set of installation instructions is included with order. Please call 1-800-526-7887 with any questions.