

DSH

Downspout Hanger

DESCRIPTION

The downspout hanger is used to prevent damage to the de-icing cable as it enters a downspout and to support the de-icing cable once inside of the downspout.

Use one downspout hanger for each de-icing cable entering or exiting the top of the downspout.


Instructions are included on backside of this page.

CONTENTS


- One Downspout Hanger
- Two Plastic Clip Ties




INSTALLING THE DSH




Detail 1. Downspout hanger and Plastic Clip Ties.




Detail 2. Bend the downspout hanger 90°. Insert clip ties through the holes.



Detail 3. Position the downspout hanger and de-icing cable and tighten the clip ties. Trim off excess clip tie.



Detail 4. The downspout hanger and de-icing cable should be centered on the edge of the downspout to prevent abrasion of the de-icing cable and support it in the downspout.



Detail 5. Use the downspout hanger to protect the de-icing cable from abrasion when going over the edge of the gutter.

TECHNICAL SUPPORT

A full set of installation instructions is included with order. Please call 1-800-526-7887 with any questions.